

P/N 91551

INDOOR THERMOMETER WITH HYGROMETER

SPECIFICATIONS

Temperature range: 32F – 122F (0C – 50C)

If temperature exceeds this range, either 32F or 122F (0C or 50C) will be displayed.

Humidity range: 20% - 95%

If humidity exceeds this range, either 20% or 95% will be displayed.

BATTERY INSTALLATION

The battery door is located at the back of the unit. Slide open the battery door. Install (1) AAA size battery into the battery compartment according to the polarity markings. Slide the battery door back into place.

DISPLAY

1. The LCD screen will automatically display the temperature and humidity. Allow 30 minutes for adjustment to the current readings.
2. Temperature can be displayed in degF or degC. The F/C button is located at the back of the unit. Press the button to display either F or C.

MIN/MAX FEATURE

1. Press the MAX button to display the maximum temperature reading since the unit was last reset. "MAX" will show on the LCD.
2. Press the MIN button to display the minimum temperature reading since the unit was last reset. "MIN" will show on the LCD.
3. In either MAX or MIN mode, press the CLEAR button to reset the memory. The unit will begin to track the new MAX and MIN readings.