

SPRINGFIELD®

PRECISETEMP™

5 IN 1 DIGITAL DESKTOP ORGANIZER WITH EVENT ALERT

Model No. 91590 Instruction Manual




FEATURES AND SPECIFICATIONS

- Indoor thermometer – °C / °F selectable
- 23 hr. 59 min. countdown timer
- 12/24 hour selectable clock with alarm and snooze function
- Calendar with day of the week display
- Programmable event alert with a selection of 8 musical sounds
- Accessory holder
- Requires (1) CR2025 button cell battery (included)

BATTERY INSTALLATION

- Slide the silver clock / thermometer LCD unit downward and separate it from the plastic accessory holder.
- Locate the battery compartment at the back of the unit and remove the screw holding the battery compartment door.
- Open the door and remove the plastic battery insulator.
- Replace the battery door. Do not over-tighten the screw.



OPERATING INSTRUCTIONS

The  button will allow you to scroll through the various display and adjustment modes. The sequence is 1) normal time mode 2) 12/24 hr. select 3) alarm mode 4) event reminder mode 5) countdown timer mode 6) back to normal time mode. Instructions for all the following settings begin with the display in normal time mode. If any other mode is on the display and no buttons are pushed, the unit will automatically revert to the normal time display after one minute.


•C / •F Selection

- Press SET to display the temperature in °Celsius or °Fahrenheit.

Setting the Clock and Calendar

- Press the  button and 12 Hr. will be flashing.
- Press ▼ or ▲ to select 12 or 24 hour timing.
- Press SET and the hour will be flashing.
- Press ▼ or ▲ to set the hour.
- Press SET and the minutes will be flashing.
- Press ▼ or ▲ to set the minutes.
- Press SET and the year will be flashing.
- Press ▼ or ▲ to set the year.
- Press SET and the month will be flashing.
- Press ▼ or ▲ to set the month.
- Press SET and the date will be flashing.
- Press ▼ or ▲ to set the date.
- Press  twice to lock in the settings.

Setting the Alarm

- Press  to display the alarm time / setting screen.
- Press SET and the alarm hour will be flashing.
- Press ▼ or ▲ to set the alarm hour.
- Press SET and the alarm minutes will be flashing.
- Press ▼ or ▲ to set the alarm minutes.
- Press SET and the music selection number will be flashing.
- Press ▼ or ▲ to select the music.
- Press SET to lock in the settings. ALARM will show at the top of the display.
- After one minute the unit will revert to the normal time display.

Silencing the Alarm



- After the alarm has sounded, press any button to silence the alarm.
- The ALARM icon will remain on the display and the alarm will sound every day at the pre-set time until the alarm is de-activated.

Setting the Snooze Function


When snooze is activated, the alarm will sound every 4 minutes up to a total of 4 times after the alarm sounds initially. The snooze function must be enabled after the alarm is set, but prior to reaching the alarm time.

- After you have set the alarm and the unit has returned to the normal time display, press ▲ to enable the snooze function. (SNOOZE will show at the top of the display).
- When the alarm sounds press any button to silence the alarm. (SNOOZE will blink, indicating the snooze function is activated). The alarm will sound again in 4 minutes.
- To de-activate snooze, press ▲ any time except when the alarm is sounding.

De-activating the Alarm


- Press  to display the alarm setting screen.
- Press SET 5 times.
- Press  3 times to return to the normal time display.
- The alarm is disabled. ALARM will no longer be shown at the top of the display.

COUNTDOWN TIMER

- Press  four times to get to the timer display.
- Press SET and the hours will be flashing.
- Press ▼ or ▲ to set the hours.
- Press SET and the minutes will be flashing.
- Press ▼ or ▲ to set the minutes.
- Press SET and the timer will begin countdown. (TIMER will flash at the top of the display).
- When the alert sounds press any button to stop the audible signal.

EVENT ALERT

This feature will allow you to pre-program the alarm to sound at any time within the calendar setting range. (current to year 2099).

- Press  three times to get to the event alert display.
- Press SET and the hour will be flashing.
- Press ▼ or ▲ to set the hours.
- Press SET and the minutes will be flashing.
- Press ▼ or ▲ to set the minutes.
- Press SET and the year will be flashing.
- Press ▼ or ▲ to set the year.
- Press SET and the month will be flashing.
- Press ▼ or ▲ to set the month.
- Press SET and the date will be flashing.
- Press ▼ or ▲ to set the date.
- Press SET to lock in the settings.

MUSIC

Your organizer will play music at any time. When the display is on normal time press the ▼ button to start the music. The music icon will show at the top of the display and the unit will loop through the musical selections. Press ▼ to turn off the music.

RESET

At any time the unit can be reset, which will clear all stored data. Locate the RESET at the front of the unit. Insert the end of a paper clip into the RESET hole and push the button. Re-enter your clock, calendar and alarm settings.

LIMITED WARRANTY

Springfield warrants this product to be free from defects in workmanship or material for a period of one year from the date of purchase. **ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTIES OF FITNESS AND MERCHANTABILITY ARE HEREBY**

LIMITED IN DURATION TO A PERIOD ENDING ONE YEAR FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights, which vary, from state to state. During the warranty period, such defects will be repaired or the defective instrument will be replaced at our option. This warranty does not cover damages through accident or misuse. **IN ADDITION, SPRINGFIELD IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES INCURRED AS A RESULT OF DEFECT.** Repair or replacement will be made at our option without additional charge if the instrument is returned postpaid with \$4.00 for return postage and handling to:



76 Passaic Street, Wood-Ridge, NJ 07075-1091

1-888-809-3284

Made in China

©2005 Springfield Precision Instruments, Inc.

All Rights Reserved